

# Make-Up Table Assembly Procedure

Product Information Bulletin #2730

Step 1. Attach the table bottom cover as shown below. Use the screws that are already installed in the holes on the bottom side of the table.

Step 2. The make-up arm attaches to the end of the table with the single leg. To mount the make-up arm, remove the lower of the two capscrews securing the table top to the table base. Put the capscrew through the lower hole of the make-up arm and screw it back into place, leaving it loose enough so that the make-up arm can be pivoted. Remove the upper capscrew, pivot the make-up arm into place, then replace the capscrews. Tighten both capscrews.

Step 3. Attach the transfer arm to the backside of the make-up table using the two capscrews located near the corner.

Step 4. Attach the speed control knob on the variac and secure with the two set screws recessed into the knob.

